

AKK14

Asennusohje
Installation instruction
Monteringsanvisning
Montasjeveiledning
Installationsvejledning

Technical Information

Rated voltage.....250 V
Max. current.....6 A
Protection class.....IP XX




ABB Oy
PL 16 (Porvoon Sisäkehä 2)
06101 PORVOO
Vaihde 010 2211

www.abb.fi/asennustuotteet

ABB Oy
P.O. Box 16 (Porvoon Sisäkehä 2)
FI-06101 PORVOO
FINLAND

Main exchange tel. +358 10 2211

Power and productivity
for a better world™

